

# MediTouch ST - Laser Mouse

optical silicone mouse for medical and industrial applications

- ▶ fully sealed
- ▶ free of interstice
- ▶ water and dust-proof (IP68)
- ▶ comfortable touch-scroll-function
- ▶ laser sensor for maximum precision on nearly every surface



The hygienic MediTouch ST - Laser Mouse provides a maximum precision on nearly every surface. It was developed specifically for medical and industrial areas and offers a comfortable handling due to the touch-scroll-function. The housing of the MediTouch ST - Mouse is fully sealed with silicone and free of interstice. This allows an quick and easy cleaning and also prevents the ingress of fluids or dust according to IP 68.

▶ Technical Data:	
Item No.:	2010329
Position recognition:	Laser sensor
Resolution:	1500 dpi
Number of keys:	2 Keys + touch-scroll-function
Degree of protection:	IP68
Key stroke:	1,4 mm
Actuating Force:	0,9 N
Operating Reliability:	>10 Mio. activities
Type:	desktop
Connector :	USB
Power Supply:	35mA@5V
Dimensions (WHD):	65 x 115 x 41 mm
Temperature (operating):	0°C to +60°C
Humidity:	up to 100%

**MediTouch**



Errors and omissions excepted.